

Dosage of detergents


Washing colored textiles

Here are selected:

- Colored detergent
- Rinse aid not selected
- Low dosage

Here are selected:

- Rinse program
- Rinse aid not selected
- Low dosage





Washing of white textiles

Here are selected:

- White detergent
- Rinse aid selected
- Medium dosage

Here are selected:

- Soap and fabric softener not selected
- Use your own soap



Washing woolen textiles

Here are selected:

- Wool detergent
- Rinse aid not selected
- High dosage

When the washing machine has started, it is not possible to change the selected detergent

